

## 2009 Scheduled Maintenance Intervals

| liles (in thousands)   | 5/25/45/65/85/105/125            | 15/55/95   | 35/75/115  |
|--|----------------------------------|--|--|
| ilometers (in thousands) 8   | 8/40/70/100/130/160/200          | 25/85/145  | 55/115/175   |
|  | -                                |  | -  |
| ngine Oil/Oil Filter – change oil and replace filter   | •                                | •  | •  |
| /iper Blades – check condition and replace if necessary  | •                                | •  | •  |
| /iper/Washer/Headlight Washer – check adjustment and function, add fluid if necessary  | •                                | •  | •  |
| ires and Spare – check for wear and damage, check pressure   | •                                |  | 115K only  |
| <ul> <li>- check for wear and damage, check pressure and renewal date of<br/>tire set (where applicable)</li> </ul>  |                                  | •  | 35K and 75K only   |
| <b>dBlue Fluid</b> – fill completely with fresh fluid (23 liters)  | Audi Q7 3.0L TDI only            | Audi Q7 3.0L TDI only  | Audi Q7 3.0L TDI only  |
| ires – rotate  | 5K only                          |  |  |
| ervice Reminder Display – reset  | •                                | •  | •  |
| rake System – check for damage, leaks, pad thickness, fluid level  | •                                | •  | •  |
| ooling System – check level, add if necessary  |                                  | •  | •  |
| xhaust System – check for damage, leaks  |                                  | •  | •  |
| ngine On-Board Diagnostics – check fault memory  |                                  | A3, A4 Cabriolet, S4, A6, S6,<br>A8 and S8 only                                      | A3, A4 Cabriolet, S4, A6, S6,<br>A8 and S8 only  |
| ngine Compartment – check for leaks  |                                  | •  | •  |
| attery – check and replace if necessary  |                                  | •  | •  |
| ust and Pollen Filter – replace  |                                  | •  | •  |
| utomatic Transmission and Final Drive – check for leaks  |                                  | •  | •  |
| Ianual Transmission and Final Drive – check for leaks  |                                  | •  | •  |
| aldex Clutch – change oil  |                                  |  | A3 and TT only   |
| ront Axle – check for excessive play, check dust seals on ball joints and tie rod ends   |                                  | A3, A4 Cabriolet, S4, A6, S6,<br>A8 and S8 only                                      |  |
| i <b>ghts</b> – check all lights, check headlight adjustment   |                                  | A8 and S8 only   | <ul> <li>A3, A4 Cabriolet, S4, A6, S6,<br/>A8 and S8 only</li> </ul>   |
| rive Shaft Boots – check   |                                  | •  | •  |
| ront Sunroof Drains (where applicable) – open sunroof to check front water drain<br>nd clean if necessary (U.S. only)  |                                  |  | •  |
| lenum Panel – remove cover to plenum panel to check water drains and clean necessary (U.S. only)   |                                  |  | A6, A6 Avant, S6, A8 and S8  |
| oors – lubricate doors, check straps and hood latch  |                                  | A8 and S8 only   | except A8 and S8   |
| park Plugs – replace at 35,000 miles or 3 years, whichever occurs first.<br>Then, every 40,000 miles or 3 years, whichever occurs first.   |                                  |  | <ul> <li>35K and 115K only: A4 2.0L TFSI,<br/>A5 2.0L TFSI, TTS, A3 3.2L,<br/>TT 3.2L and A8 6.0L only</li> </ul>                    |
| <ul> <li>replace at 55,000 miles or 6 years, whichever occurs first.</li> <li>Then, every 60,000 miles or 6 years, whichever occurs first.</li> <li>replace at 75,000 miles</li> </ul> |                                  | 55K only: except A3 3.2L,<br>TT 3.2L, A4 2.0L TFSI,<br>A5 2.0L TFSI, TTS and A8 6.0L | 75K only: A3 3.2L, TT 3.2L,<br>A4 2.0L TFSI, A5 2.0L TFSI,   |
|  |                                  |  | A4 2.0L TFSI, A5 2.0L TFSI,<br>TTS and A8 6.0L only  |
| ontinuously Variable Transmission (multitronic) – change ATF<br>ower Steering Fluid – check, add if necessary  |                                  |  | •  |
| ir Cleaner – clean housing, replace filter element   |                                  | 55K only: except Audi Q7 4.2L<br>and A8 6.0L   | <ul> <li>35K only: A8 6.0L only;</li> <li>75K only: Audi Q7 4.2L,</li> <li>A8 6.0L only;</li> <li>115K only; A8 6.0L only</li> </ul> |
| ibbed V Belt and Tensioner – check condition and replace if necessary  |                                  | Audi R8 only   | Audi Q7 3.6L, A8 6.0L, Audi R8 or  |
| ibbed V Belt - replace   |                                  |  | 75K only: S4 only  |
| <ul> <li>check condition, replace if necessary. Check tension of belt drive<br/>with manual tensioner and retension if necessary.</li> </ul>   |                                  |  | 75K only: V6 FSI, V6 TFSI (rear be<br>2.0L TFSI, 5.2L FSI, 4.2L V8 FSI   |
| - replace only the V belt for the compressor drive   |                                  |  | 75K only: 3.0L TFSI only   |
| now Screen for Air Cleaner - clean   |                                  | A4, A5, S5 and A6 only   | A4, A5, S5 and A6 only   |
| nderbody – check for damage and leaks  |                                  | •  | •  |
| oad Test – check braking, kick-down, steering, electrical, heating and ventilation<br>stems, air conditioning, ASL Automatic Shift Lock and power accessories                          |                                  | •  | •  |
| ear Lid Hinges – lubricate   |                                  | A8 and S8 only   | A8 and S8 only   |
| orn – check function   |                                  |  |  |
| rake Discs – check thickness   |                                  |  | •  |
| ights – check all lights via instrument cluster. Check license plate light from the rear   |                                  |  |  |
| f the vehicle  |                                  |  | <ul> <li>Audi Q7, A4, S4, Audi Q5, TT,<br/>A5, S5 and Audi R8 only</li> </ul>  |
| <b>nterior Lights</b> – check all interior lights, glove box illumination, control lights<br>nd MMI (if applicable)  |                                  |  | •  |
| SG/S Tronic – change oil and replace filter element  |                                  |  | A3 and TT only   |
| uel Filter – remove water  |                                  | Audi Q7 3.0L TDI only  |  |
| - replace  |                                  |  | Audi Q7 3.0L TDI only  |
| iesel Particle Filter (DPF) – check ash content within the DPF. Replace DPF with an ash  | 125K only: Audi Q7 3.0L TDI only |  |  |

At 110K miles (175,000 km) replace timing belt on Audi TT 2.0L with front-wheel drive, Audi TTS and A4 Cabriolet 2.0T only. Check condition of timing belt tensioning system, dampening pulleys, and idler pulleys and replace if necessary (Audi TT 2.0T with front-wheel drive, Audi TTS and A4 Cabriolet 2.0T only).

Audi of America, Inc. believes the information and specifications to be correct at the time of printing. Specifications, maintenance intervals, standard features and options subject to change without notice.